
Assembly & Installation Instructions: Sierra 2-Leg Desk SEHX78-90-XXX-XX-X



Parts Included



WARNING: Maximum loading of table assembly is 225 lb. (102 kg.). Maximum load includes the weight of the table top itself, any equipment placed upon it, and any equipment suspended or hanging under it. Loading should be evenly distributed over table surfaces. "Payload Capacity" is the Workrite Ergonomics recommended maximum loading which includes the Workrite sourced worksurface.

Sierra 2-Leg

V = 120 VAC, 60 Hz / 4.25 A maximum

FLAMMABILITY: All worksurfaces used must meet UL962 flammability requirements

- Flame Spread Rating maximum 200
- Smoke Developed Index maximum 450

WORKSURFACE SIZE: This frameset is designed to accommodate worksurfaces made from Industrial Particle Board with the following dimensions:

Dimensions (inches):

Rectangles: 76"-88"w x 23"-29"d

IMPORTANT SAFETY INSTRUCTIONS:

When using an electrical furnishing, basic precautions should always be followed, including the following: Read all instructions before using this Sierra Work center.

DANGER: To reduce the risk of electric shock, always unplug this Sierra Work center from the electrical outlet before cleaning.

WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1. Unplug from outlet before putting on or taking off parts.
- 2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
- 3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
- 5. Keep the cord away from heated surfaces.
- 6. Do not use outdoors.
- 7. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 8. To disconnect, remove plug from outlet.
- 9. Each surface intended to support an equipment payload capacity of 225 pounds.

FOR COMMERCIAL USE ONLY

SAVE THESE INSTRUCTIONS



IMPORTANT NOTE!


You must complete initialization (Step 13) at the end of assembly or your work center WILL NOT FUNCTION PROPERLY.



Verify that you have all the tools needed for the assembly

You will need the following tools:

#2 tip Phillips screwdriver or drill/driver #3 tip Phillips screwdriver or drill/driver M4 tip bit or 4 mm Allen Wrench (E)



If you do not have a Workrite worksurface, you will also need:

1/8" pilot drill bit 3/32" pilot drill bit




Assemble Rear Brackets Set

Assemble Rear Brackets (Q) to Connector Bracket (R) using #M6 × 12 mm Flat Head Cap Screws (U).

Use this guide to determine the correct holes for mounting based on the width of your work center.

Tighten securely.


Hardware at actual size



Note!

Only use the #M6 × 12 mm Flat Head Cap Screw (U) for assembly.

Note: Workrite Brackets can be sized in 3" increments for any non-Workrite top. Keep bracket construction as symmetrical as possible for best support.




To avoid stripping the threads, always

2 Attach Brackets to Legs

- **2.1** Attach Short Brackets (B) using #M6 × 14 mm Flat Head Cap Screws (F) to both legs.
- **2.2** Attach Left End Bracket (C) and Right End Bracket (D) to sides of the Leg (A) using #M6 × 14 mm Flat Head Cap Screws (F).
- 2.3 Attach Rear Bracket Assembly to sides of the Leg (A) using #M6 × 14 mm Flat Head Cap Screws (F).

Note: The Right End Bracket will be on your left and vice versa when the assembly is seen upside down.

Tighten securely.




3 Attach Base to Worksurface

3.1 Position Leg Assembly centered left to right and 6.125" from the front of the worksurface, making sure the frame runs




Note: Avoid trip or tip hazards! For uniquely shaped, non-rectangular worksurfaces, it is the installers responsibility to position the worksurface to minimize extended overhangs and position feet fully under the worksurface.



4 Attach Base to the drilled Worksurface

4.1 Attach at the four corner locations using $#12 \times 3/4$ " Pan Head Laminate Top Screws (G). If you use an electric screwdriver, be sure it is on the lowest torque setting to avoid stripping the holes in the top.


4.2 With frame set positioned and the four corner screws secure, drill all remaining pilot holes first then install all remaining #12 × 3/4" Pan Head Laminate Top Screws (G).




5 Attach Feet & Install Foot Glides

- **5.1** Install feet (S) using #M6 × 14 mm Flat Head Screws(F) included with this Frame Set.
- **5.2** Attach Foot Glide (H) to bottom of the Feet supplied in your Foot Kit.

Hardware at actual size




Caution! Only use the #M6 × 14 mm Flat Head Cap Screw (F) for assembly.



Flat Foot shown


6 Attach Switch

- **6.1** Using the dimensions shown place the Switch (T) on the desktop
- **6.2** Using a Drill and a ³/₃₂" drill bit, drill the two switch mounting holes as shown.
- **6.3** Attach the Switch (T as shown with two (2) #8 x 5%" Pan Head Screws (L)




Programmable Switch shown

Note: The Switch (T) can be located on the Right or Left side of the table as required.



Loop Power Cord through Strain Relief on Control Box

- **7.1** Loop the Power Cord (O) thought the strain relief channel on the bottom of the Control Box (I) as shown. Leave eight inches of slack to rout cord.
- **7.2** Plug Power Cord (O) into port AC on the Control Box (I).
- **7.3** Lay the Control Box down in installation location with cables in place.




8 Attach Control Box & Cable Spools to Worksurface

8.1 Place Control Box (I) in position and use a pencil to mark pilot hole placement. Control Box should be placed towards rear center of worksurface as shown. Remove Control Box and drill pilot holes where marked.


Do not drill all the way through worksurface!

- **8.2** With Control Box (I) positioned over pilot holes, attach with two #12 × 2" Flat Head Screws (J).
- **8.3** Attach Cable Spool (K) with the #12 × ¾" Pan Head Screw (G) to underside of worksurface. If you do not have a Workrite worksurface, mount Cable Spools (K) in a convenient location between Legs and Control Box.
- **8.4** Lay out Leg Cables (N) to be sure they reach from the Legs (A) to the Control Box (I).




9 Attach Cable Loops and Route Cables

- **9.1** Connect both of the 1 meter Leg Cables (N) to both Legs (A).
- **9.2** Wind any remaining slack around Cable Spools (K) to keep cables out of the way while leaving enough slack to just reach the Control Box (I).
- **9.3** Attach Cable Loops (M) to underside of worksurface using #8 × 5%" Pan Head Screw (L) making sure to wrap the Cable Loop around the cable prior to attaching. Attach cable loops in convenient locations between Legs or Switch and the Control Box.




10 Connect Leg Cables, Switch Cable and Power Cord to Control Box

- 10.1 Connect the Leg Cables (N) to the ports "1" & "2" on both sides of the Control Box (I).
- **10.2** Insert the Switch Cable into port "A1" on the Control Box (I).



Put Work center Upright and Connect Power Cord to the Power Supply

11.1 Turn the work center over into an upright position.




12 Adjust Feet Glides

If necessary, adjust the Foot Glides (H) on work center feet to level the worksurface. Unscrew to increase height, screw in to decrease height.

13 Initialize Legs

After all Legs and the Switch are connected, and the power cord has been plugged in, hold the **down arrow** on the Switch until the Legs make a short motion down and then back up. This initializes and synchronizes the work center Legs.



Hold down the down arrow until work center moves slightly upwards!

✓ Cleaning Instructions

To clean the Sierra legs, apply cleaner to a soft cloth.

Suggested cleaners: Windex or Formula 409.

Do not use solvents and do not saturate or spray cleaners directly onto work center base.

Parts & Accessories

Visit http://workriteergo.com/documentation/other/workrite_ergonomics_pricing_specification_guide.pdf for replacement parts.